

















































Quick Reference Chart (Embroidery Mode)








 Category Selection	
	Select Design
	Select Monogram
	Select Edit mode







 Embroidery Pattern and Ready to Sew Screen	
	Browse designs by category
	Browse designs by hoop size
	Show color section of design
	Color list
	Pattern tracing
	Open manual setting window
	Move carriage to home position
	Stitch back/forward keys
	Jump to the entered sewing point
	① Jog keys
	② Display current sewing point
	View previous/next color section
	Return to previous pattern selection



 Monogramming			
	Font selection		Save monogram design
	Lettering orientation		Adjust spacing size
	Letter size		Move cursor left/right and select letter
	Letter case		
	Delete selected pattern		

 Embroidery Edit Screen	
	Display other editing tools
	Confirm settings
	Return to category selection
	① Move pattern
	② Move pattern to center of edit screen
	Select pattern
	Select hoop size
	Resize pattern
	Duplicate pattern
	Delete pattern
	Open Rotation option window
	Create Vertical/Horizontal mirror image
	Open Arc layout window
	Open Group all/selected patterns window
	Create vertical, horizontal and diagonal mirror images
	Arrange sewing order
	Change background and pattern colors (see next page)
	Group and unite patterns by thread colors
	Sew patterns in one color
	Magnifying Edit screen
	Grab and drag Edit screen
	Save embroidery patterns

Quick Reference Chart (Embroidery Mode)

  Change Background and Pattern Color	
	Design color key
	Background color key
	Rename key
	Background image key
	Default key

  Monogramming Ready to Sew Screen	
	Stop monogramming to change thread color
	Left alignment
	Center alignment
	Right alignment

 Ready to Sew Screen (Sewing AcuFil Design)	
	Flip design pattern